

SHAD


PIAGGIO LIBERTY 125 '09- KIT TOP VOLB19ST



1 260523 x2
Ø16 Ø9 x 25



2 260821 x1
Ø16 Ø9 x 22



3 261262 x1



4 304152 x1
M6 x 50 DIN 7991



5 303017 x2
Ø6



6 302021 x3
Ø6



7 304221 x2
M6 x 45 DIN 7380



8 303052 x3
Ø6

! WARNING!

(GB)

Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

(E)

No apretar los tornillos del todo hasta asegurarse que el KIT está correctamente colocado y alineado.

(D)

Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist.

(I)

Non stringere del tutto le viti fin tanto non si è sicuri che il kit è collocato correttamente e allineato.

(F)

Ne pas serrer les vis avant d'être sûr que le KIT est correctement monté et ajusté.

